

# Mini Squirt® Hot Melt Adhesive Applicator



*Portable adhesive dispensing system delivers efficient hot melt adhesive application.*



The compact, handheld Mini Squirt hot melt adhesive applicator provides reliable bonding for small, simple applications. The portable design makes it easy to handle and the wire stand provides freestanding support on convenient work surfaces. The Mini Squirt applicator's clean, quiet operation is ideal for office and light industrial environments.

The Mini Squirt adhesive applicator is easy to operate. Plug-in the all-electric unit and fill the tank with hot melt adhesive. The applicator is ready for use after a 10 to 15 minute warm-up.

The tank reservoir holds up to 7 ounces of adhesive in a variety of forms: granule, chicklet or pillow.

- **Lightweight, portable design** for use in office and light industrial environments.
- **Tank reservoir** accommodates various adhesive forms.
- **Trigger-activated piston plunger** assures smooth operation.
- **A variety of dispensing nozzles** is available to meet specific requirements

## Mini Squirt® Hot Melt Adhesive Applicator



Holds variety of adhesive forms.



Adjustable thermostat controls.

### Specifications

#### Tank Capacity

Dry	4 oz (113 g)
Fluid	7 oz (198 g)

Warm-up Time (max.) 15 minutes

Dispense Rate 4 oz/min (0.12 l/min)

Temperature Range Adjustable up to 375° F (190° C)

Electrical 110/115 V, 2A max  
230 V, 1A max

Weight 2.6 lb (1.18 kg)

#### Nozzles

Extended Single Orifice (diameter)	0.070 in (1.8 mm)
Single Orifice (diameter)	0.040, 0.070 or 0.100 in (1.0, 1.8 or 2.5 mm)
Slot Swivel (slot width)	0.300 or 0.700 in (7.6 or 17.8 mm)

Nozzle kit includes one (1) each of single orifice and slot swivel nozzle.

For more information, talk with your Nordson representative or contact your Nordson regional office.

#### United States

Duluth, Georgia  
Telephone: (800) 683-2314  
Toll-free Facsimile:  
(866) 667-3329

#### Canada

Markham, Ontario  
Telephone: (800) 463-3200  
Facsimile: (905) 475-8821

#### Europe

Lüneburg, Germany  
Telephone: (49) 4131-894-0  
Facsimile: (49) 4131-894-149

#### Japan

Tokyo, Japan  
Telephone: (81) 3-5762-2700  
Facsimile: (81) 3-5762-2701

#### Asia/Australia/ Latin America

Amherst, Ohio  
Telephone: (440) 985-4797  
Facsimile: (440) 985-1096

[www.nordson.com](http://www.nordson.com)



When you expect more.®